

NuMicro PinView Tool User Manual

The information described in this document is the exclusive intellectual property of Nuvoton Technology Corporation and shall not be reproduced without permission from Nuvoton.

Nuvoton is providing this document only for reference purposes of NuMicro™ microcontroller based system design. Nuvoton assumes no responsibility for errors or omissions.

All data and specifications are subject to change without notice.

For additional information or questions, please contact: Nuvoton Technology Corporation.

Table of Contents

1	Introduction	4
1.1	Supported Chips and Packages	4
1.2	System Requirements.....	8
1.2.1	Hardware	8
1.2.2	Software	8
1.3	Functional Description	9
1.3.1	Standalone Version	9
1.3.2	Plug-In for Keil/IAR IDE	9
1.4	Features	10
1.4.1	Display the selected pin function	10
1.4.2	Display the pin configuration	10
1.4.3	Display an alert for abnormal pin	11
1.4.4	User-defined chip setting script.....	11
2	Getting Started	12
2.1	Running PinView	12
2.2	Main Window	14
3	Revision History	15

List of Figures

Figure 1-1 Standalone PinView	9
Figure 1-2 PinView Plug-In for IAR IDE	10
Figure 2-1 Nu-Link Keil Debug Menu	12
Figure 2-2 Nu-Link IAR Debug Menu.....	13
Figure 2-3 Main Window of PinView	14

1 Introduction

NuMicro PinView Tool (abbreviated as PinView in the following) is a monitoring and visualization tool that can show the current status of I/O pins on the device immediately, and inform users of some common pin configuration errors. It can run as a standalone application or be used as a plug-in for Keil/IAR IDE.

1.1 Supported Chips and Packages

Please refer to the datasheets from <http://www.nuvoton.com>.

AU9100 series

- AU9110AN , LQFP48

M031 series

- M031AE , TSSOP20/TSSOP28/QFN33/LQFP48/LQFP64
- M032AE , LQFP48/LQFP64

M051 series

- M052/M054/M058/M0516AN , QFN33/LQFP48
- M052/M054/M058/M0516BN , QFN33/LQFP48
- M052/M054/M058/M0516DN , QFN33/LQFP48
- M052/M054/M058/M0516DE , QFN33/LQFP48

M0518 series

- M0518AE , LQFP48/LQFP64

M0519 series

- M0519AE , LQFP48/LQFP64/LQFP100

M0564 series

- M0564AE , LQFP48/LQFP64/LQFP100

M058S series

- M058SAN , TSSOP20/QFN33/LQFP48/LQFP64



M2351 series

- M2351AE , QFN33/LQFP64/LQFP128

M251 series

- M251AE , TSSOP20/TSSOP28/QFN33/LQFP48/LQFP64/LQFP128
- M252AE , TSSOP20/TSSOP28/QFN33/LQFP48/LQFP64/LQFP128

M451 series

- M451AE , LQFP48/LQFP64/LQFP100
- M452AE , LQFP48/LQFP64
- M453AE , LQFP48/LQFP64/LQFP100
- M451MAE , LQFP48

M4521 series

- M4521AE , LQFP48/LQFP64

M480 series

- M481AE , QFN33/LQFP48
- M482AE , ULQFP48/ULQFP64
- M483AE , HSULQFP64/HSULQFP128
- M484AE , HSULQFP64/HSULQFP128/UHSULQFP64
- M485AE , HSULQFP64/HSULQFP128
- M487AE , HSULQFP64/HSULQFP128/HSULQFP144

Mini51 series

- Mini51/Mini52/Mini54AN , QFN33/LQFP48
- Mini51/Mini52/Mini54DE , TSSOP20/QFN33/LQFP48
- Mini55DE , QFN33/LQFP48
- Mini58DE , TSSOP20/QFN33/LQFP48

Mini57 series

- Mini57DE , TSSOP20/TSSOP28/QFN33



ML51 series

- ML51AE , MSOP10/SOP20/SOP28/TSSOP14/TSSOP20/TSSOP28
/QFN20/QFN33/LQFP32/LQFP48

NM1120 series

- NM1120AE , TSSOP20/TSSOP28/QFN20/QFN33

NM1200 series

- NM1100AE , TSSOP20/QFN20
- NM1200AE , QFN33/LQFP48

NM1500 series

- NM1510AE , LQFP48
- NM1530AE , LQFP100
- NM1520AE , LQFP48/LQFP64

NUC029 series

- NUC029AN , QFN33/LQFP48
- NUC029AE , TSSOP20
- NUC029DE , LQFP48/LQFP64
- NUC029EE , LQFP48/LQFP64
- NUC029GE , LQFP48/LQFP64

NUC100 series

- NUC100AN , LQFP48/LQFP64/LQFP100
- NUC120AN , LQFP48/LQFP64/LQFP100
- NUC100BN , LQFP48/LQFP64
- NUC101BN , QFN36/LQFP48
- NUC120BN , LQFP48/LQFP64
- NUC130CN , LQFP48/LQFP64/LQFP100
- NUC140CN , LQFP48/LQFP64/LQFP100
- NUC100DN , LQFP48/LQFP64/LQFP100
- NUC120DN , LQFP48/LQFP64/LQFP100



NUC121 series

- NUC121AE , QFN33/LQFP48/LQFP64

NUC122 series

- NUC122AN , QFN33/LQFP48/LQFP64

NUC123 series

- NUC123AN , QFN33/LQFP48/LQFP64
- NUC123AE , QFN33/LQFP48/LQFP64

NUC125 series

- NUC125AE , QFN33/LQFP48/LQFP64

NUC126 series

- NUC126AE , LQFP48/LQFP64/LQFP100

NUC1261 series

- NUC1261AE , LQFP48/LQFP64

NUC131 series

- NUC131AE , LQFP48/LQFP64

NUC200 series

- NUC200AN , LQFP48/LQFP64/LQFP100
- NUC220AN , LQFP48/LQFP64/LQFP100
- NUC230AE , LQFP48/LQFP64/LQFP100
- NUC240AE , LQFP48/LQFP64/LQFP100

NUC2201 series

- NUC2201AE , LQFP48/LQFP64



NUC400 series

- NUC442AE , LQFP64/LQFP100/LQFP128/LQFP144
- NUC472AE , LQFP100/LQFP128/LQFP144/LQFP176

NUC505 series

- NUC505 , QFN88/LQFP64/LQFP48

Nano100 series

- Nano100AN , QFN33/LQFP48/LQFP64
- Nano120AN , QFN33/LQFP48/LQFP64
- Nano100BN , LQFP48/LQFP64/LQFP128
- Nano110BN , LQFP64/LQFP128
- Nano120BN , LQFP48/LQFP64/LQFP128
- Nano130BN , LQFP64/LQFP128

Nano103 series

- Nano103AE , LQFP33/LQFP48/LQFP64

Nano112 series

- Nano102AN , LQFP33/LQFP48/LQFP64
- Nano112AN , LQFP48/LQFP64/LQFP100

1.2 System Requirements

1.2.1 Hardware

- Nu-Link In-Circuit Emulator(ICE)

1.2.2 Software

- Please download the standalone version of PinView or the Keil/IAR plug-in version which is included in Nu-Link driver (v1.25.6287 or higher) from nuvoton website, and click the installer file to start the installation wizard. Follow the instructions in the installation wizard to complete the installation.

1.3 Functional Description

1.3.1 Standalone Version

The standalone PinView can monitor the I/O pins on the device without stopping the process of target chip and let users view the pin status updates in real-time. Also, it allows users to load user-defined lua script through the menu **File** → **Run Script** at the top of the main window to access the chip memory or register, stop a running target, etc. The main window is shown as follows:




Figure 1-1 Standalone PinView

1.3.2 Plug-In for Keil/IAR IDE

To use PinView plug-in for Keil/IAR IDE, it's necessary to start a debugging session first and then execute it from the debug menu. For each debug step, it can display the variation in I/O pin status and refreshes the status information periodically until a breakpoint or program exit is reached. The PinView plug-in's main window of IAR IDE is shown as follows:




Figure 1-2 PinView Plug-In for IAR IDE

1.4 Features

1.4.1 Display the selected pin function

Identify the pin function using the background and text colors:

- As a general-purpose input/output (GPIO) pin, it shows in blue color.
- As a peripheral device pin (e.g., UART, SPI, PWM), it shows in other colorful colors except blue.
- Others, it shows in gray color.

1.4.2 Display the pin configuration

If you move the mouse cursor over the pin, a pop-up tooltip that includes one or more of the following descriptions will show up:

- The value of multi-function and clock setting registers corresponding to the current pin.
- The text of input and output state descriptions for GPIO.

- The clock source and frequency of peripheral device.
- The baud rate of universal asynchronous receiver/transmitter (UART) device.
- The sampling frequency of Pulse-width modulation (PWM) device.

1.4.3 Display an alert for abnormal pin

While detecting the pin in an abnormal status, the pin number will be displayed in red color. Meanwhile, if you move the mouse cursor over the pin, the pop-up tooltip will show the cause messages in red color. The possible abnormal status is described as follows:

- The electrical leakage for GPIO pin.
- The value of multi-function setting register is undefined.
- The clock source of peripheral device is unavailable.
- The baud rate setting of UART device exceeds the valid range.
- The pre-scale register setting of PWM device is invalid.

1.4.4 User-defined chip setting script

For standalone PinView, it allows user to load user-defined lua script to interact with target chip.

2 Getting Started

2.1 Running PinView

- To execute the standalone PinView, click the **Start button** in the lower-left corner of your screen to open the **Start Menu**, and then select the **Nuoton Tools** → **NuTool** - **PinView**.
- The PinView plug-in for Keil IDE can only be used during the debugging session. To execute it, please start a debugging session, and then click the **Debug Menu** → **NuTool** - **PinView**.




Figure 2-1 Nu-Link Keil Debug Menu

- The PinView plug-in for IAR IDE can only be used during the debugging session. To execute it, please start a debugging session, and then click the **Nu-Link Menu** → **NuTool** - **PinView**.

NuMicro PinView Tool User Manual




Figure 2-2 Nu-Link IAR Debug Menu

2.2 Main Window

The following figure provides a description for the main window of PinView.




Figure 2-3 Main Window of PinView



3 Revision History

Revision	Date	Description
0.01	Dec. 23, 2013	1. First version.
0.02	Jan. 21, 2014	1. Updated all figures.
0.03	Jan. 14, 2015	1. Changed document format.
0.04	June. 2, 2017	1. Updated "Supported Chips and Packages" chapter.
0.05	Nov. 8, 2017	1. Updated "Supported Chips and Packages" chapter : Added M2351AE
0.06	June. 7, 2018	1. Updated "Supported Chips and Packages" chapter : Added M031AE, M0519AE, and NUC030AE .
0.07	June. 13, 2018	1. Updated "Supported Chips and Packages" chapter : Added M4521AE and NUC2201AE.
0.08	June. 28, 2018	1. Updated "Supported Chips and Packages" chapter : Added NUC029DE and NUC029EE.
0.09	July. 25, 2018	1. Updated "Supported Chips and Packages" chapter : Added NM1120AE.
0.10	Aug. 6, 2018	1. Updated "Supported Chips and Packages" chapter : Added NUC1261AE and NUC029GE.
0.11	Aug. 31, 2018	1. Updated "Supported Chips and Packages" chapter : Added ML51AE.
0.12	Jan. 22, 2019	1. Updated "Supported Chips and Packages" chapter : Added M251AE.

Important Notice

Nuvoton Products are neither intended nor warranted for usage in systems or equipment, any malfunction or failure of which may cause loss of human life, bodily injury or severe property damage. Such applications are deemed, "Insecure Usage".

Insecure usage includes, but is not limited to: equipment for surgical implementation, atomic energy control instruments, airplane or spaceship instruments, the control or operation of dynamic, brake or safety systems designed for vehicular use, traffic signal instruments, all types of safety devices, and other applications intended to support or sustain life.

All Insecure Usage shall be made at customer's risk, and in the event that third parties lay claims to Nuvoton as a result of customer's Insecure Usage, customer shall indemnify the damages and liabilities thus incurred by Nuvoton.

Please note that all data and specifications are subject to change without notice.
All the trademarks of products and companies mentioned in this datasheet belong to their respective owners.