


USB2.0


USBHS_ID → USBHS_ID
 USBHS_D+ → USBHS_D+
 USBHS_D- → USBHS_D-
 USBHS_VBUS → USBHS_VBUS



POWER

VDD5 → VDD5
 VDD33 → VDD33
 VDD18 → VDD18
 VDD16 → VDD16

GND → GND
 AVDD → AVDD
 AVSS → AVSS






Audio CODEC

P55 I2C2_SCL
P56 I2C2_SDA
P2 I2S0_RCLK
P3 I2S0_MCLK
P4 I2S0_OE
P5 I2S0_DO
P6 I2S0_LRCK
P52 PCM1
P7

POWER

VDD5 >> VDD5
VDD33 >> VDD33
VDD18 >> VDD18
VDD16 >> VDD16
GND >> GND
AVDD >> AVDD
AVSS >> AVSS



OLED


P37 OSPI0_SS
P38 OSPI0_CLK
P39 OSPI0_MISO
P40 OSPI0_MOSI
P36 Rst

SPI Flash

P25 SPIM_D3
P26 SPIM_D2
P27 SPIM_SS
P28 SPIM_CLK
P29 SPIM_MISO
P30 SPIM_MOSI

SD CARD

P64 SD1_CMD
P1 SD1_CLK
P9 SD1_DAT3
P10 SD1_DAT2
P11 SD1_DAT1
P21 SD1_DAT0
SD1_M0



SPI Flash

