

SPI flash as a storage for USB MSC

NuMicro® 32 位系列微控制器範例代碼介紹

文件資訊

代碼簡述	本範例代碼使用SPI flash作為USB隨身碟的儲存空間
BSP 版本	M480 Series BSP CMSIS V3.04.000
開發平台	NuMaker-PFM-M487 Ver 3.0

The information described in this document is the exclusive intellectual property of Nuvoton Technology Corporation and shall not be reproduced without permission from Nuvoton.

Nuvoton is providing this document only for reference purposes of NuMicro microcontroller based system design. Nuvoton assumes no responsibility for errors or omissions.

All data and specifications are subject to change without notice.

For additional information or questions, please contact: Nuvoton Technology Corporation.

www.nuvoton.com

1 功能介紹

1.1 簡介

範例程式中，M480作為USB2.0隨身碟，其透過SPIM介面外接SPI Flash當作儲存空間，且帶有檔案系統(File system)，此功能可以實現替代SD卡當作儲存空間的替代方案，測試寫入速度約為每秒128位元組。

使用者須透過MSC_Init(SectorOffset, TotalSector)設定儲存記憶體起始位置，以及總共記憶體空間大小。一個Sector預設為512 KB。由於SPI Flash限制一次最少需要清除4KB，因此會先讀取4KB內容，並且刪除再重新寫入。USB處理程序在MSC_ProcessCmd()內，M480會根據所收到的指令進行相對應的處理動作。


1.2 執行結果

執行後會打印出以下資訊

```

+-----+
|      HSUSB Mass Storage Sample Code      |
| use SPI flash as back end storage through SPIM interface |
+-----+
disk size is : 2048 KB
SPIM get JEDEC ID=0xEF, 0x40, 0x16
  
```

連接NuMaker-PFM-M487上的USB2.0插槽至電腦後，出現以下隨身碟圖示



2 代碼介紹

在main.c中首先進行初始化並讀取外接SPI flash ID，接著設定隨身碟儲存起始位置與儲存空間大小，最後等待連接電腦後在MSC_ProcessCmd()內執行USB處理程序：

```
int32_t main(void)
{
    /* Init System, IP clock and multi-function I/O
       In the end of SYS_Init() will issue SYS_LockReg()
       to lock protected register. If user want to write
       protected register, please issue SYS_UnlockReg()
       to unlock protected register if necessary */
    SYS_Init();

    /* Init UART to 115200-8n1 for print message */
    UART_Open(UART0, 115200);

    printf("+-----+\n");
    printf("|          HSUSB Mass Storage Sample Code          |\n");
    printf("| use SPI flash as back end storage through SPIM interface |\n");
    printf("+-----+\n");
    printf("disk size is : %d KB\n", (disk_size*512)/1024);

    SYS_UnlockReg();

    /* SPIM init */
    SPIM_Init();

    HSUSBD_Open(&gshsInfo, MSC_ClassRequest, NULL);

    /* Massstorage init */
    MSC_Init(memory_offset, disk_size);

    /* Enable USBBD interrupt */
    NVIC_EnableIRQ(USBD20_IRQn);

    /* Start transaction */
    while (1) {
        if (HSUSBD_IS_ATTACHED()) {
            HSUSBD_Start();
        }
    }
}
```

```

        break;
    }
}
/* Massstorage process */
while (1) {
    if (g_hsusbd_Configured)
        MSC_ProcessCmd();
}
}

```

讀寫SPI flash程式碼如下:

```

/* Read data through SPIM */
void MSC_ReadMedia(uint32_t addr, uint32_t size, uint8_t *buffer)
{
    SPIM_Read(addr + g_SectorsOffset, size, buffer);
}
/* Write data through SPIM */
void MSC_WriteMedia(uint32_t addr, uint32_t size, uint8_t *buffer)
{
    SPIM_Write(addr + g_SectorsOffset, size, buffer);
}

```

3 軟體與硬體環境


● 軟體環境

- BSP 版本
 - ◆ M480 Series BSP CMSIS V3.04.000
- IDE 版本
 - ◆ Keil uVersion 5.26

● 硬體環境







- 電路元件
 - ◆ NuMaker-PFM-M487 or other M480 Development Board
- 示意圖

透過 SPIM 介面外接 SPI flash，使用硬體的方式處理傳輸協議，來提升對於 SPI flash 的讀寫速度。使用 USB2.0 OTG 插槽連接電腦，即可在電腦端看到隨身碟。



4 目錄資訊

EC_M480_HSUSBD_MassStorage_SPIMFlash_V1.00

 Library	Sample code header and source files
 CMSIS	Cortex [®] Microcontroller Software Interface Standard (CMSIS) by Arm [®] Corp.
 Device	CMSIS compliant device header file
 StdDriver	All peripheral driver header and source files
 SampleCode	
 ExampleCode	Source file of example code

5 如何執行範例程式

1. 根據目錄資訊章節進入 ExampleCode 路徑中的 KEIL 資料夾，雙擊 HSUSBD_MassStorage_SPIMFlash.uvproj
2. 進入編譯模式介面
 - a. 編譯
 - b. 下載代碼至記憶體
 - c. 進入 / 離開除錯模式
3. 進入除錯模式介面
 - a. 執行代碼

6 修訂紀錄

Date	Revision	Description
Oct. 01, 2019	1.00	1. 初始發布.

Important Notice

Nuvoton Products are neither intended nor warranted for usage in systems or equipment, any malfunction or failure of which may cause loss of human life, bodily injury or severe property damage. Such applications are deemed, "Insecure Usage".

Insecure usage includes, but is not limited to: equipment for surgical implementation, atomic energy control instruments, airplane or spaceship instruments, the control or operation of dynamic, brake or safety systems designed for vehicular use, traffic signal instruments, all types of safety devices, and other applications intended to support or sustain life.

All Insecure Usage shall be made at customer's risk, and in the event that third parties lay claims to Nuvoton as a result of customer's Insecure Usage, customer shall indemnify the damages and liabilities thus incurred by Nuvoton.

*Please note that all data and specifications are subject to change without notice.
All the trademarks of products and companies mentioned in this datasheet belong to their respective owners.*